



NORTH EAST COLOR

Asphalt Decal

INSTALLATION GUIDE

ver. 033123

For Support Call: 603.436.8210



Two Persons are
Recommended
for this Installation

1. Only apply on a dry day with low humidity.
2. Before application remove loose dirt from the surface. Very dirty surfaces may require washing, but the surface must be fully dry before application.



3. Remove one small strip of liner from the back side.



4. Orient the graphic, gently apply the exposed edge and then slowly remove the rest of the liner.



5. Use your fingers, a soft roller or squeegee to work the material into any deep texture or cracks.
6. Use a hard rubber roller to activate the adhesive. Roll up and down the film slowly, with firm pressure to ensure adhesion. Be sure to apply roller pressure to all areas and angles of the print/application surface.

