Standoff Hardware Installation Guide

For best installation results, please consult this guide when installing our standoffs.

NORTH EAST COLOR



Gather tools and signs.



2 Place sign on the wall to mark the holes for the standoffs.



Drill pilot holes (use anchors, if needed).



4 Using a long screwdriver extension, thread the screw through the barrel.



5 Screw barrel onto wall.



6 Place sign over holes and attach caps loosely.



Tighten each cap until snug (do not over tighten).